



Application Note:

ACUITY Operation Mapping and Support List

Revision 1.12
14 December 2021

Legal Notices

COPYRIGHT INFORMATION

This document contains proprietary information of Vivante Corporation. Vivante Corporation reserves the right to make changes to any products herein at any time without notice. Vivante Corporation does not assume any responsibility or liability arising out of the application or use of any product described herein, except as expressly agreed to in writing by Vivante Corporation; nor does the purchase or use of a product from Vivante Corporation convey a license under any patent rights, copyrights, trademark rights, or any other of the intellectual property rights of Vivante Corporation or third parties.

DISCLOSURE/RE-DISTRIBUTION LIMITATIONS

This document contains proprietary information of Vivante Corporation. The information contained in this Vivante Confidential document may be directly re-distributed or may be adapted for re-distribution by Vivante customer SoC vendors who have licensed the related core IP, with the understanding that re-distribution is limited to those customers of the SoC vendor who have active and valid NDA or licenses applicable for the SoC which contains the related Vivante core IP. Otherwise, the information contained herein is not to be used by or disclosed to the third parties without the express written permission of an officer of Vivante Corporation.

(Vivante Distribution LEVEL B: CONFIDENTIAL – DISTRIBUTION RESTRICTED)

Upon request Vivante provides this document in Word format for adaptive inclusion in documentation intended for your customers. Vivante requests a pre-release copy of the adaptation for review and approval. In the adapted document please include a reference to the copyright owner, for example: "This chapter contains copyright confidential and proprietary material disclosed with permission of Vivante Corporation. Vivante has authorized re-distribution of this material restricted to those NDA partners and licensees of [the SoC vendor] who are engineering [SoC vendor's product] which includes the discussed Vivante IP."

TRADEMARK ACKNOWLEDGMENT

Vivante Corporation and the Vivante Corporation logo design are the trademarks or the registered trademarks of Vivante Corporation. All other brand and product names may be trademarks of their respective companies.

For our current distributors, sales offices, design resource centers, and product information, visit our web page located at <http://www.verisilicon.com>.

For technical support, please email vivante-support@verisilicon.com.

Vivante Corporation Confidential, Copyright © 2021 by Vivante Corporation. All rights reserved.

Table of Contents

Legal Notices.....	1
Table of Contents	2
Preface.....	3
1 Operation Mappings Between NN Networks and ACUITY	4
1.1 Supported NN Frameworks.....	4
1.2 TF to ACUITY Operation Mapping	5
1.3 TFLite to ACUITY Operation Mapping	7
1.4 Keras to ACUITY Operation Mapping	9
1.5 ONNX to ACUITY Operation Mapping	10
1.6 Caffe to ACUITY Operation Mapping	12
1.7 Darknet to ACUITY Operation Mapping.....	13
2 ACUITY to OVXLIB Operation Mapping.....	14
Document Revision History	17



Preface

This document provides neural network operation mappings between ACUITY, OVXLIB, and high level neural network (NN) frameworks.

This document contains the following chapters:

- *1, Operation Mappings Between NN Networks and ACUITY*
- *2, ACUITY to OVXLIB Operation Mapping*

For the compatible ACUITY, OVXLIB and Unified Driver versions, see the *Document Revision History* Chapter.

For the supported NN frameworks, see *Section 1.1, Supported NN Frameworks*.



1 Operation Mappings Between NN Networks and ACUITY

The chapter contains the following sections:

- *1.1, Supported NN Frameworks*
- *1.2, TF to ACUITY Operation Mapping*
- *1.3, TFLite to ACUITY Operation Mapping*
- *1.4, Keras to ACUITY Operation Mapping*
- *1.5, ONNX to ACUITY Operation Mapping*
- *1.6, Caffe to ACUITY Operation Mapping*
- *1.7, Darknet to ACUITY Operation Mapping*

1.1 Supported NN Frameworks

ACUITY translates the following NN frameworks into its own formats. Then, ACUITY exports them into OpenVX applications for use with the Vivante Unified Driver.

The supported NN frameworks include:

- TensorFlow (TF) 2.6.0
- TensorFlow Lite (TFLite) generated from TF 2.3.0
- Keras generated from TF 2.6.0
- ONNX 1.10.2
- Caffe
- Darknet



1.2 TF to ACUITY Operation Mapping

The following table lists the operation mapping between TensorFlow (TF) and ACUITY.

For the supported TF version, see [Section 1.1, Supported NN Frameworks](#).

TF Operation	ACUITY Operation
tf.abs	abs
tf.add / tf.nn.bias_add	add
tf.add_n	addn / add
tf.argmin	argmin
tf.argmax	argmax
tf.batch_to_space_nd	batch2space
tf.nn.batch_normalization	batchnormalize / instancenormalize / layernormalize / batchnorm_single
tf.nn.fused_batchnorm	batchnormalize
tf.cast	cast
tf.clip_by_value	clipbyvalue
tf.concat	concat
tf.nn.conv1d	conv1d
tf.nn.conv2d / tf.nn.depthwise_conv2d / tf.nn.conv1d	convolution
tf.nn.conv3d	conv3d
tf.image.crop_and_resize	cropsandresize
tf.nn.conv2d_transposed	deconvolution
tf.depth_to_space	depth2space
tf.equal	equal
tf.exp	exp
tf.nn.elu	elu
tf.nn.embedding_lookup	embedding_lookup
tf.erf	erf
tf.maximum	eltwise(MAX)
tf.floor	floor
tf.matmul	fullconnect

TF Operation	ACUITY Operation
tf.floordiv	floor_div
tf.gather_nd	gathernd
tf.gather/ tf.nn.embedding_lookup	gather
tf.nn.gelu	gelu
tf.nn.rnn_cell_GRUCell tf.nn.dynamic_rnn	gru
tf.nn.rnn_cell_GRUCell	gru_cell
tf.greater	greater
tf.greater_equal	greater_equal
tf.image.resize_bilinear / tf.image.resize_nearest_ neighbor	image_resize
tf.contrib.layers.instance_norm / tf.nn.fused_batch_norm	instancenormalize
tf.nn.local_response_normalization	localresponsenormalization_tf
tf.nn.l2_normalize	l2normalize
tf.nn.rnn_cell_LSTMCell / tf.nn_dynamic_rnn	lstm
tf.rnn_cell.LSTMCell	lstm_unit
tf.less	less
tf.less_equal	less_equal
tf.logical_or	logical_or
tf.logical_add	logical_and
tf.nn.leaky_relu	leakyrelu
tf.multiply	multiply
tf.nn.moments	moments
tf.minimum	minimum
tf.matmul / tf.batch_matmul	matmul

TF Operation	ACUITY Operation
tf.not_equal	not_equal
tf.negative	neg
tf.one_hot	one_hot
tf.pad	pad
tf.transpose	permute
tf.nn.avg_pool / tf.nn.max_pool / tf.reduce_mean	pooling
tf.nn.max_pool_with_ argmax	poolwithargmax
tf.pow	pow
tf.reduce_any	reduceany
tf.reduce_max	reducemax
tf.reduce_mean	reducemean
tf.reduce_sum	reducesum
tf.reverse / tf.reverse_sequence	reverse
tf.nn.relu	relu
tf.nn.relu6	relun
tf.rsqrt	rsqrt
tf.realdiv	real_div
tf.repeat	repeat

TF Operation	ACUITY Operation
tf.reshape / tf.expand_dims / tf.squeeze	reshape
tf.round	round
tf.strided_slice	stridedslice
tf.sqrt	sqrt
tf.square	square
tf.subtract	subtract
tf.scatter_nd	scatternd
tf.stack	stack
tf.nn.sigmoid	sigmoid
tf.signal.frame	signalframe
tf.slice	slice
tf.nn.softmax	softmax
tf.space_to_batch_nd	space2batch
tf.space_to_depth	space2depth
tf.split	split
tf.nn.swish	swish
tf.tile	tile
tf.nn.tanh	tanh
tf.unstack	unstack
tf.where/tf.select	where



1.3 TFLite to ACUITY Operation Mapping

The following table lists the operation mapping between TensorFlow Lite (TFLite) and ACUITY.

For the supported TFLite version, see [Section 1.1, Supported NN Frameworks](#).

TFLite Operation	ACUITY Operation
ADD	add
ADD_N	addn
ARG_MAX	argmax
ARG_MIN	argmin
AVERAGE_POOL_2D / MAX_POOL_2D	pooling
ABS	abs
BATCH_TO_SPACE_ND	batch2space
CAST	cast
CONV_2D / DEPTHWISE_CONV_2D	convolution
CONCATENATION	concat
DEPTH_TO_SPACE	depth2space
DEQUANTIZE	dequantize
DIV	divide
ELU	elu
EMBEDDING_LOOKUP	embedding_lookup
EXP	exp
EQUAL	equal
EXPAND_DIMS	expanddims
FLOOR_DIV	floor_div
FLOOR	floor
FULLY_CONNECTED	fullconnet / fullconnet_op
GATHER_ND	gathernd
GATHER	gather
GREATER	greater
GREATER_EQUAL	greater_equal
HARD_SWISH	hard_swish
LOGICAL_OR	logical_or

TFLite Operation	ACUITY Operation
LOCAL_RESPONSE_NORMALIZATION	localresponsenormalization
LOGISTIC	sigmoid
LSTM	lstmunit
L2_NORMALIZATION	l2normalize
L2_POOL_2D	l2pooling
LESS_EQUAL	less_equal
LOGICAL_AND	logical_and
LOGICAL_NOT	logical_not
LOG_SOFTMAX	log_softmax
LESS	less
LEAKY_RELU	leakyrelu
MAXIMUM	maximum
MUL	multiply
MEAN	reducemean
MIRROR_PAD	pad
NON_MAX_SUPPRESSION_V5	nms
NOT_EQUAL	not_equal
NEG	neg
ONE_HOT	one_hot
POW	pow
PACK	stack
PAD / PADV2	pad
PRELU	prelu
RANK	rank
REDUCE_ANY	reduceany
REDUCE_MIN	reducemin
RSQRT	rsqrt
REDUCE_MAX	reducemax
RELU	relu

TFLite Operation	ACUITY Operation
RELU1 / RELU_N1_TO_1 / RELU6	relun
RESIZE_BILINEAR/RESIZE_NEAREST_NEIGHBOR	image_resize
REVERSE_SEQUENCE	reverse_sequence
REVERSE_V2	reverse_v2
ROUND	round
SCATTER_ND	scatternd
SEGMENT_SUM	segment_sum
SELECT	where
SHAPE	shapelayer
SIN	sin
SQUEEZE / RESHAPE	reshape
SPLIT / SPLIT_V	split
SOFTMAX	softmax
SPARSE_TO_DENSE	sparse_to_dense
SVDF	svdf
SQUARE	square
SQUARED_DIFFERENCE	squared_difference

TFLite Operation	ACUITY Operation
SUB	subtract
SUM	reducesum
SLICE	slice
SPACE_TO_BATCH_ND	space2batch
STRIDED_SLICE	stridedslice
SPACE_TO_DEPTH	space2depth
TOPK / TOPK_V2	topk
TRANSPOSE_CONV	deconvolution
TRANSPOSE	permute
TILE	tile
TANH	tanh
UNIQUE	unique
UNPACK	unstack
UNIDIRECTIONAL_SEQUENCE_LSTM	lstm
WHERE	where



1.4 Keras to ACUITY Operation Mapping

The following table lists the operation mapping between Keras and ACUITY.

For the supported Keras version, see [Section 1.1, Supported NN Frameworks](#).

Keras Operation	ACUITY Operation
Add	add
Activation(relu)	relu
Activation(sigmoid)	sigmoid
Activation(softmax)	softmax
Activation(tanh)	tanh
BatchNormalization / BatchNormalizationV1	batchnormalize
Conv1D	conv1d
Conv2D	convolution
Conv2DTranspose	deconvolution
Conv3D	conv3d
ConvLSTM2D	conv2d_lstm
Cropping2D	slice
Concatenate	concat
DepthwiseConv2D	depthwise_convolution
Dense	fullconnect
Embedding	embedding_lookup
Flatten / Reshape	reshape
GRU	gru
LeakyRelu	leakyrelu

Keras Operation	ACUITY Operation
LSTM	lstm
Maximum	maximum
Minimum	minimum
Multiply	multiply
MaxPooling2D / AveragePooling2D / GlobalAveragePooling2D / GlobalMaxPooling2D	pooling
Permute	permute
PReLU	prelu
ReLU	relu_keras
RNN	keras_rnn_lstm
SeparableConv2D	depthwise_convolution
Subtract	subtract
SimpleRNN	lstm_keras
Softmax	softmax
ThresholdedReLU	relun
UpSampling2D	image_resize
ZeroPadding2D	pad

1.5 ONNX to ACUITY Operation Mapping

The following table lists the operation mapping between ONNX and ACUITY.

For the supported ONNX version, see [Section 1.1, Supported NN Frameworks](#).

Note: In the table, [operations in blue](#) are either added or updated in this release.

ONNX Operation	ACUITY Operation
ArgMin	argmin
ArgMax	argmax
Add	add
Abs	abs
And	logical_and
BatchNormalization	batchnormalize
Clip	clipbyvalue
Cast	cast
CastLike	cast
Ceil	ceil
Celu	celu
Concat	concat
ConvTranspose	deconvolution / deconvolution1d
Conv	conv1d / group_conv1d / depthwise_conv1d / convolution / conv2d_op / depthwise_conv2d_op / conv3d
Cumsum	cumsum
Div	divide
Dropout	dropout
DepthToSpace	depth2space
DequantizeLinear	dequantize
Einsum	einsum
Equal	equal
Erf	erf
Exp	exp
Elu	elu
Expand	expand_broadcast
Floor	floor

ONNX Operation	ACUITY Operation
InstanceNormalization	instancenormalize
Gemm	matmul / fullconnect
Gather	gather
Greater	greater
GreaterOrEqual	greater_equal
GatherND	gathernd
GRU	gru
HardSigmoid	hard_sigmoid
HardSwish	hard_swish
Logsoftmax	log_softmax
LRN	localresponsenormalization
Log	log
LeakyRelu	leakyrelu
Less	less
LessOrEqual	less_equal
LSTM	lstmlstm
MatMul	matmul / fullconnect
Max	eltwise(MAX)
MaxPool / AveragePool / GlobalAveragePool / GlobalMaxPool	pooling / pool1d / pool3d
MaxRoiPool	roipooling
Mean	eltwise(MEAN)
MeanVarianceNormalization	instancenormalize
Min	eltwise(MIN)
Mod	mod
Mul	multiply
Neg	neg
NonZero	nonzero
Or	logical_or

ONNX Operation	ACUITY Operation
Prelu	prelu
Pad	pad
Pow	pow
QuantizeLinear	quantize
QLinearMatMul	matmul
QLinearConv	convolution / conv1d
Relu	relu
Reshape / Squeeze / Unsqueeze / Flatten	reshape
ReduceSum	reducesum
ReduceMean	reducemean
ReverseSequence	reverse_sequence
ReduceMax	reducemax
ReduceMin	reducemin
ReduceL1	abs + reducesum
ReduceL2	reducesum + multiply + sqrt
ReduceLogSum	reducesum + log
ReduceLogSumExp	exp + reducesum + log
ReduceProd	reduceprod
ReduceSumSquare	multiply + reducesum
Reciprocal	variable + divide
Resize	image_resize
ScatterND	scatter_nd_update

ONNX Operation	ACUITY Operation
Shape	shapelayer
Sigmoid	sigmoid
Sign	sign
Sin	sin
Size	size
Slice	slice / stridedslice
Softmax	softmax
Softplus	softrelu
Softsign	abs + add + divide + variable
SpaceToDepth	space2depth
Split	split / slice
Sqrt	sqrt
Squeeze	squeeze
Sub	subtract
Sum	eltwise(SUM)
Tile	tile
Transpose	permute
Tanh	tanh
Unsqueeze	reshape
Upsample	image_resize
Where	where
Xor	not_equal

1.6 Caffe to ACUITY Operation Mapping

The following table lists the operation mapping between Caffe and ACUITY.

For the supported Caffe version, see [Section 1.1, Supported NN Frameworks](#).

Note: The current release does not support non-standard Caffe operations.

Caffe Operation	ACUITY Operation
absval	abs
axpy	a_times_b_plus_c
batchnorm / bn	batchnormalize
convolution	convolution
concat	concat
convolutiondepthwise	convolution
dropout	dropout
depthwiseconvolution	convolution
deconvolution	deconvolution
elu	elu
eltwise	eltwise
flatten	flatten
innerproduct	fullconnect
lrn	localresponsernormalization
l2normalizescale	l2normalizescale
leakyrelu	leakyrelu
lstm	lstm
normalize	l2normalize
poolwithargmax	poolwithargmax

Caffe Operation	ACUITY Operation
permute	permute
prelu	prelu
pooling	pooling
priorbox	priorbox
proposal	proposal
reorg	reorg
roipooling	roipooling
relu	relu
reshape	reshape
reverse	reverse
swish	swish
slice	split
scale	multiply
shufflechannel	shuffle
softmax	softmax
sigmoid	sigmoid
tanh	tanh

1.7 Darknet to ACUITY Operation Mapping

The following table lists the operation mapping between Darknet and ACUITY.

For the supported Darknet version, see [Section 1.1, Supported NN Frameworks](#).

For more details about Darknet, visit <https://pjreddie.com/darknet/>.

Darknet Operation	ACUITY Operation
avgpool	pooling
batch_normalize	batchnormalize
connected	fullconnect
convolutional	convolution
depthwise_convolutional	convolution
leaky	leakyrelu
logistic	sigmoid
maxpool	pooling
mish	mish
region	region

Darknet Operation	ACUITY Operation
reorg	reorg
relu	relu
route	concat / slice
softmax	softmax
shortcut	add/slice + add/pad + add
scale_channels	multiply
swish	swish
upsample	upsampling
yolo	yolo



2 ACUITY to OVXLIB Operation Mapping

The following table lists the mapping between the ACUITY operations and the OVXLIB operations.

Note 1: The OVXLIB operation prefix VSI_NN_OP_ is omitted from the following table.

Note 2: In the table, [operations in blue](#) are either added or updated in this release.

ACUITY Operation	OVXLIB Operation
abs	ABS
add	ADD
addn	ADDN
argmin	ARGMIN
argmax	ARGMAX
a_times_b_plus_c	A_TIMES_B_PLUS_C
batchnorm_single	BATCHNORM_SINGLE
batch2space	BATCH2SPACE
batchnormalize	BATCH_NORM
cast	DATACONVERT / CAST
ceil	CEIL
celu	Not available currently
conv3d	Not available currently
concatshift	CONCATSHIFT
crop	CROP
concat	CONCAT
conv2d_op	CONV2D
convolution	CONV2D
conv1d	CONV1D
conv2d_lstm	CONV2D_LSTM
conv3d	CONV3D
cos	Not available currently
clipbyvalue	CLIP
convolutionrelu	CONV_RELU
convolutionrelupool	CONV_RELU_POOL
depth2space	DEPTH2SPACE
downsample	RESIZE
divide	DIVIDE
dropout	DROPOUT
dtype_converter	DATACONVERT
dequantize	DATACONVERT

ACUITY Operation	OVXLIB Operation
depthwise_conv2d_op	CONV2D
depthwise_convolution	CONV2D
deconvolution	DECONVOLUTION
deconvolution1d	DECONVOLUTION1D
depthwise_conv1d	DEPTHWISE_CONV1D
embedding_lookup	EMBEDDING_LOOKUP
einsum	Not available currently
erf	ERF
expand_broadcast	EXPAND_BROADCAST
exp	EXP
elu	ELU
equal	RELATIONAL_OPS_EQUAL
fullconnectrelu	FCL_RELU
fullconnect_op	FCL2
floor	FLOOR
floor_div	FLOORDIV
floor_mod	Not available currently
fullconnectaxis	FCL2
fullconnectreluaxis	FCL2
fullconnect	FCL
gelu	GELU
greater	RELATIONAL_OPS_GREAT
greater_equal	RELATIONAL_OPS_GREAT_EQUAL
groupnormalize	GROUP_NORM
gather	GATHER
gathernd	GATHER_ND
gru	GRU
gru_cell	GRUCELL
group_conv1d	CONV1D
hard_sigmoid	HARD_SIGMOID

ACUITY Operation	OVXLIB Operation
hard_swish	HSWISH
image_resize	RESIZE
instancenormlize	INSTANCE_NORM
lstm	LSTM_OVXLIB
Localresponsernormalization_tf	LRN2
l2normalizescale	L2NORMALIZESCALE
l2pooling	POOL
log_softmax	LOG_SOFTMAX
log	LOG
l2normalize	L2_NORMALIZE
layernormalize	LAYER_NORM
lstmunit	LSTMUNIT_OVXLIB
leakyrelu	LEAKY_RELU
less	RELATIONAL_OPS_LESS
less_equal	RELATIONAL_OPS_LESS_EQUAL
logical_and	LOGICAL_AND
logical_not	LOGICAL_NOT
logical_or	LOGICAL_OR
localresponsernormalization	LRN
minimum	MINIMUM
max	ELTWISEMAX
mod	Not available currently
moments	MOMENTS
mish	MISH
matmul	MATRIXMUL
maximum	MAXIMUM
multiply	MULTIPLY
neg	NEG
nms	Not available currently
nonzero	Not available currently
not_equal	RELATIONAL_OPS_NOT_EQUAL
one_hot	ONE_HOT
prelu	PRELU
pow	POW
proposal	PROPOSAL
pooling / pool1d	POOL
poolwithargmax	POOLWITHARGMAX
pad	PAD
permute	PERMUTE
quantize	DATA CONVERT

ACUITY Operation	OVXLIB Operation
rank	Not available currently
real_div	DIVIDE
reducemax	REDUCE_MAX
reducemin	REDUCE_MIN
reorg	REORG
repeat	REPEAT
relu	RELU
rsqrt	RSQRT
relun	RELUN / CLIP
relu_keras	RELU_KERAS
reduceany	REDUCE
reducemean	REDUCE_MEAN
reduceprod	Not available currently
reducesum	REDUCE_SUM
reshape	RESHAPE
reverse_sequence	REVERSE_SEQUENCE
reverse	REVERSE
reverse_v2	Not available currently
resizebilinear_image / resizenearest_image	RESIZE
roipooling	ROI_POOL
round	ROUND
sequence_mask	SEQUENCE_MASK
sigmoid	SIGMOID
scatter_nd_update	SCATTER_ND_UPDATE
segment_sum	Not available currently
shapelayer	Not available currently
sign	Not available currently
size	Not available currently
sparse_to_dense	Not available currently
squared_difference	Not available currently
squeeze	RESHAPE
square	SQUARE
subtract	SUBTRACT
slice	SLICE
space2batch	SPACE2BATCH
swish	SWISH
shuffle	SHUFFLECHANNEL
svdf_ext	SVDF
spatialtransformer	SPATIAL_TRANSFORMER
signalframe	SIGNAL_FRAME



ACUITY Operation	OVXLIB Operation
space2depth	SPACE2DEPTH
split	SPLIT
stridedslice	STRIDED_SLICE
stack	STACK
stack_concat	TENSORSTACKCONCAT
softmax	SOFTMAX
softrelu	SOFTRELU
sin	SIN
sqrt	SQRT
scatternd	SCATTER_ND

ACUITY Operation	OVXLIB Operation
tanh	TANH
tile	TILE
topk	TOPK
upsampling	RESIZE
upsample	UPSAMPLE
unique	Not available currently
unstack	UNSTACK
variable	VARIABLE
where	WHERE



Document Revision History

This section describes changes of each document revision.

Revision	Date	Compatible Software	Change History
1.12	2021-12-14	<ul style="list-style-type: none"> ACUITY 6.3.x and later Unified Driver 6.4 and later OVXLIB 1.1.37 and later 	<ul style="list-style-type: none"> Section 1.1, Supported NN Frameworks: <ul style="list-style-type: none"> Updated the support of TensorFlow 2.3.0 to TensorFlow 2.6.0. Updated the supported TensorFlow version for Keras model generation from 2.3.0 to 2.6.0. Updated the support of ONNX 1.8.0 to ONNX 1.10.2. Section 1.5, ONNX to ACUITY Operation Mapping: Added the following ONNX operations and their ACUITY equivalents: CastLike, Cumsum, HardSwish, and MaxRoiPool. Chapter 2, ACUITY to OVXLIB Operation Mapping: Added the ACUITY operation conv3d and its OVXLIB equivalent.
1.11	2021-09-22	<ul style="list-style-type: none"> ACUITY 6.0.0 and later Unified Driver 6.4 and later OVXLIB 1.1.34 and later 	<ul style="list-style-type: none"> Section 1.2, TF to ACUITY Operation Mapping: Added the TF operation <code>tf.nn.gelu</code> and its ACUITY equivalent. Section 1.4, Keras to ACUITY Operation Mapping: Added the Keras operation ConvLSTM2D and its ACUITY equivalent. Section 1.5, ONNX to ACUITY Operation Mapping: Added the ONNX operation HardSigmoid and its ACUITY equivalent. Chapter 2, ACUITY to OVXLIB Operation Mapping: <ul style="list-style-type: none"> Added the following ACUITY operations and their OVXLIB equivalents: <code>conv2d_lstm</code> and <code>gelu</code>. Updated the ACUITY operation <code>gru</code> with its OVXLIB equivalent changed to GRU. Updated the ACUITY operation <code>gru_cell</code> with its OVXLIB equivalent changed to GRUCELL. Updated the ACUITY operation <code>lstm</code> with its OVXLIB equivalent changed to LSTM_OVXLIB. Added the OVXLIB equivalent for the ACUITY operation <code>scatter_nd_update</code>.

Revision	Date	Compatible Software	Change History
1.10	2021-06-28	<ul style="list-style-type: none"> ACUITY 5.24.0 and later Unified Driver 6.4 and later OVXLIB 1.1.32 and later 	<ul style="list-style-type: none"> Section 1.1, Supported NN Frameworks: Updated the support of ONNX 1.6.0 to ONNX 1.8.0. Section 1.2, TF to ACUITY Operation Mapping: Added the following TF operations and their ACUITY equivalents: <code>tf.erf</code>, <code>tf.one_hot</code>, <code>tf.reduce_any</code>, <code>tf.reduce_max</code>, <code>tf.repeat</code>, and <code>tf.round</code>. Section 1.3, TFLite to ACUITY Operation Mapping: Added the following TFLite operations and their ACUITY equivalents: <code>ELU</code>, <code>LOGICAL_NOT</code>, <code>NON_MAX_SUPPRESSION_V5</code>, <code>ONE_HOT</code>, <code>PADV2</code>, <code>RANK</code>, <code>REDUCE_ANYREVERSE_SEQUENCE</code>, <code>REVERSE_V2</code>, <code>ROUND</code>, <code>SCATTER_ND</code>, <code>SEGMENT_SUM</code>, <code>SELECT</code>, <code>SHAPE</code>, <code>SIN</code>, <code>SPLIT_V</code>, <code>SPARSE_TO_DENSE</code>, <code>SQUARED_DIFFERENCE</code>, <code>TOPK/TOPK_V2</code>, and <code>UNIQUE</code>. Section 1.4, Keras to ACUITY Operation Mapping: Added the following Keras operations and their ACUITY equivalents: <code>Conv3D</code>, <code>Maximum</code>, <code>Minimum</code>, and <code>Permute</code>. Section 1.5, ONNX to ACUITY Operation Mapping: <ul style="list-style-type: none"> Added the following ONNX operations and their ACUITY equivalents: <code>Ceil</code>, <code>Celu</code>, <code>Einsum</code>, <code>Erf</code>, <code>GreaterOrEqual</code>, <code>LessOrEqual</code>, <code>Mean</code>, <code>MeanVarianceNormalization</code>, <code>Mod</code>, <code>NonZero</code>, <code>ReduceProd</code>, <code>ScatterND</code>, <code>Shape</code>, <code>Sign</code>, <code>Size</code>, and <code>Unsqueeze</code>. Updated the ONNX operation <code>Conv</code> with an ACUITY equivalent <code>conv3d</code> added. Updated the ONNX operation <code>MaxPool/AveragePool/GlobalAveragePool/GlobalMaxPool</code> with an ACUITY equivalent <code>pool1d</code> added. Chapter 2, ACUITY to OVXLIB Operation Mapping: <ul style="list-style-type: none"> Added the following ACUITY operations and their OVXLIB equivalents: <code>ceil</code>, <code>erf</code>, <code>groupnormalize</code>, <code>logical_not</code>, <code>one_hot</code>, <code>pool1d</code>, <code>repeat</code>, <code>reduceany</code>, <code>reverse_sequence</code>, <code>round</code>, <code>sequence_mask</code>, and <code>topk</code>. Specified the ACUITY operations that are not mapped to OVXLIB. Refined the document structure and content.
1.03	2020-12-25	<ul style="list-style-type: none"> ACUITY 5.18.0 and later Unified driver 6.4.5 and later OVXLIB 1.1.29 and later 	<ul style="list-style-type: none"> Section 2, Deep Learning Framework-ACUITY Operation Mapping: Updated the compatible version of TensorFlow to 2.3.0. Section 2.3, TFLite to ACUITY Mapping: Added the TFLite operation <code>DEPTH_TO_SPACE</code> and its ACUITY equivalent. Section 2.4, ONNX to ACUITY Mapping: Updated the ONNX operation <code>ConvTranspose</code> with an ACUITY equivalent <code>deconvolution1d</code> added. Section 3, ACUITY to OVXLIB Mapping: Added the ACUITY operation <code>deconvolution1d</code> and its OVXLIB equivalent.

Revision	Date	Compatible Software	Change History
1.02	2020-09-23	<ul style="list-style-type: none"> ACUITY 5.16.0 and later Unified driver 6.4.4 and later OVXLIB 1.1.27 and later 	<ul style="list-style-type: none"> Section 2: Updated the version of TensorFlow API from 1.13 to 2.0.0. Section 2.2: Added TensorFlow operation: <code>tf.cast</code>. Section 2.3: Added TFLite operations: ARGMAX, ARGMIN, SUM, and MIRROR_PAD. Section 2.4: <ul style="list-style-type: none"> Added ONNX operations: DequantizeLinear, Expand, QuantizeLinear, QLinearMatMul, QLinearConv, Reciprocal, and Resize. Updated ONNX operations: Slice and Split. Section 2.6: <ul style="list-style-type: none"> Updated the version of TensorFlow from 1.13.x to 2.0.0. Removed Keras operation: Dropout. Section 3: <ul style="list-style-type: none"> Added ACUITY operations: <code>expand_broadcast</code> and <code>scatternd</code>. Updated ACUITY operation: <code>cast</code>.
1.01	2020-07-24	<ul style="list-style-type: none"> ACUITY 5.15.0 and later Unified driver 6.4.3.1 and later OVXLIB 1.1.25 and later 	<ul style="list-style-type: none"> Section 2.2: Added TensorFlow operation: <code>tf.nn.conv1d</code>. Section 2.4: Added ONNX operations: GRU, LSTM, Min, MaxPool/AveragePool, ReduceL1, ReduceL2, ReduceLogSum, ReduceLogSumExp, ReduceSumSquare, Softsign, Softplus, Sin, and Xor. Section 2.5: <ul style="list-style-type: none"> Added Darknet operation: <code>mish</code>. Updated Darknet operations: <code>logistic</code>, <code>route</code>, and <code>shortcut</code>. Section 2.6: <ul style="list-style-type: none"> Removed Keras operation: SimpleRNN. Updated Keras operation: LSTM. Section 3: Added ACUITY operation: <code>sin</code>.
1.00	2020-07-09	<ul style="list-style-type: none"> ACUITY 5.14.0 and later Unified driver 6.4.3 and later OVXLIB 1.1.24 and later 	<ul style="list-style-type: none"> Initial release Adapted from Vivante.AppNote.VIP.Neural.Network.Layer.and.Operation.Support v1.1.7 Updated format of all tables. Deleted Section 4.